



SANDSTONE CLEANING, SEALING & MAINTENANCE GUIDE

PRE-SEALING

*When using sandstone around saltwater pools, or in harsh salt water environments such as seaside residences we recommend using **Spirit Premium Consolidator**. Methods of application include spraying, brushing, microfibre applicator, and dip sealing for complete and total consolidation. Contact Spirit Sealers for more information on stone consolidation.

If **Spirit Premium Consolidator** is not used in the above environments, we recommend using **Spirit Pre Seal** as an alternative prior to laying to provide added water resistance, helping to keep salts from building within the stone.

Spirit Pre Seal is excellent for use as a grout release for hard to grout surfaces and pointing on walls.

In these types of installations, we recommend the face and sides are pre-sealed and, in some circumstances, all six sides of the stone can be pre-sealed with **Spirit Pre Seal**. The same methods of application apply.

IMPORTANT! Do not stack the drying stone against each other with no air flow, stack them so they can breathe, and remove any excess sealer within 5 minutes.

Contact Spirit Sealers if you are unsure about pre-sealing.

INITIAL CLEANING/GROUT HAZE REMOVAL

Once the stone has been laid, grouted and washed, a grout residue/haze may be left. It is recommended to wait for 3-4 days for the grout to harden sufficiently before attempting to remove the grout haze in preparation for sealing.

It is advised to keep the area protected during this timeframe if work is still being done by other trades, as they may need to work over or near your freshly laid sandstone.

What you will need – (**Spirit Phosphoric Acid, Spirit Neutral Cleaner, Spirit Doodlebug**, bucket, broom, mop.) **Spirit Safe Acid** can also be used to remove the grout haze.

IMPORTANT! Test first for acid sensitivity before cleaning any surface with **Spirit Phosphoric Acid** or **Spirit Safe Acid**. If the stone shows acid sensitivity, use **Spirit HDC** to remove the grout haze.

1. Sweep and or vacuum the area to remove any loose debris.
2. In a bucket, dilute 10 parts clean water to 1 part **Spirit Phosphoric Acid** or **Safe Acid** and apply to the area that needs cleaning. Use a broom to evenly distribute the solution over the area.
3. Allow the solution to sit for 2-3 mins. If you notice that the solution is drying, add more cleaner to keep it wet. Only clean in sections that you can handle.
4. Now scrub the area with a **Spirit Doodlebug** (scouring pad.) The multi-directional head attaches easily to a broom handle for easy cleaning in hard-to-reach areas.
5. Remove the solution and rinse the area with **Spirit Neutral Cleaner**.



SEALING

Once the sandstone is clean and dry, final sealing can begin. It is recommended that a breathable penetrating sealer is used. Test first before use, preferably on a spare piece of stone.

- **Spirit Premium Seal** is the best choice. **Spirit Water Based Premium Seal** and **Spirit NPS** are also suitable. *If consolidation has been done with **Spirit Premium Consolidator**, only **Spirit Premium Seal** or **Spirit NPS** can be used.

What you will need – (Sealer, **Spirit Microfibre Applicator**, clean white rags, gloves, respirator and solvent suitable tray (for solvent-based sealer only.)

2 coats are required, allowing approximately 1 hour in between coats. Follow the directions on the can or bottle very closely.

Please note: Penetrating sealers will not prevent surface etching or scuffing.

MAINTENANCE -The sandstone can be cleaned regularly using **Spirit Neutral Cleaner**. If need be, the stone can be cleaned periodically (every 6-12 months) depending on traffic and wear with **Spirit HDC** or **Spirit Bright As**.

RE-SEALING

Please note: Weather conditions, harsh cleaning methods using high-alkaline, acid or solvent-based cleaners will affect the long-term performance of any sealer. Following the appropriate **Spirit Guide** relating to your substrate will ensure the very best protection. The longevity of your sealer and the protection it provides is greatly dependant on the following 4 points...

1. Using a premium quality sealer.

Spirit Sealers are all premium quality sealers.

2. Proper application of the sealer. This includes the cleaning process prior to sealing.

Sealing a floor that hasn't properly dried, sealing when it's too hot or cold, not mopping up excess sealer and not applying enough sealer are a few of the mistakes made.

3. Where the sealed area is? Is it a high traffic area?

Commercial areas that see more traffic and are cleaned daily will need re-sealing before most domestic areas; however, in domestic situations like, outdoor areas, high traffic internal areas and shower cubicles, these areas will need to be re-sealed more often. If in doubt, contact Spirit Sealers.

4. How the floor is maintained?

Cleaning regularly with the wrong types of cleaners will break down the sealer prematurely and may even do damage to your sandstone. The cleaners in this guide have been formulated especially for the stone and tile industry.

This is a general guide for Sandstone. Spirit Sealers always recommends to test first when cleaning or sealing any surface. For more technical information contact sales@spiritsealers.com